




# SPARE PARTS

## & COMPLETE UNITS



MORRIS MINOR S.V. & FAMILY EIGHT O.H.V. 1932.



CE 67



JOSEPH LUCAS LTD., BIRMINGHAM, ENGLAND

Γ NO. C.E. 67.

1932/4.

MARCH '14





## DESCRIPTION.

Quote this Part No.

English  
Retail Prices.  
£ s. d.


	<b>STARTER COMPLETE—6v. E.R. CLK. (O.H.V. &amp; S.V.)—</b>	<b>M35A/0 A11/0</b>	<b>5 10 0 each</b>
1	Armature complete ... ..	M35/AY904	1 17 6 each
2	Brush Spring ... ..	M35/L2144/6A	1 0 dozen
	Commutator End Bracket c/w Brushes, Brush Gear and Bearing Bush ... ..	O.H.V. & S.V.	
3	Commutator End Band Cover complete ... ..	O.H.V. & S.V.	
4	D.E. Bracket complete with Bearing Bush ... ..	O.H.V. & S.V.	
5	Main Spring ... ..	O.H.V. & S.V.	
6	Pinion and Sleeve ... ..	O.H.V. & S.V.	
	Set of Field Coils ... ..	O.H.V. & S.V.	
7	Set of Brushes ... ..	O.H.V. & S.V.	
	Set of Nuts, Screws & Washers ... ..	O.H.V. & S.V.	
8	Through Fixing Bolt ... ..	O.H.V. & S.V.	
	<b>DYNAMO COMPLETE—6v. E.R. ANTI—(O.H.V.)—</b>	<b>DD55</b>	<b>7 12 6 each</b>
	<b>DYNAMO COMPLETE—6v. E.R. CLOCK—(S.V.)—</b>	<b>C45E/0 A17/0</b>	<b>4 10 0 each</b>
9	Armature complete ... ..	O.H.V.	2 10 0 each
10	Armature complete ... ..	S.V.	1 12 6 each
11	C.E. Bracket c/w Brushes, Brush Gear and Bearing ... ..	O.H.V.	
	C.E. Bracket only ... ..	O.H.V.	
12	C.E. Bracket c/w Brush Gear, Brushes and Bearing Bush ... ..	S.V.	
13	Control Brush Gear Base Assembled less Bush ... ..	O.H.V.	
14	Control Brush Carrier Assem. less Bush ... ..	S.V.	
15	Commutator End Band Cover complete ... ..	O.H.V.	
16	Commutator End Band Cover complete ... ..	S.V.	
	Commutator End Ball Race ... ..	O.H.V.	
17	D.E. Bracket complete with Bearing and Bearing Plate ... ..	S.V.	
18	D.E. Bracket complete with Bearing and Clamp Plate ... ..	O.H.V.	
	Driving End Ball Race ... ..	O.H.V.	
	Driving End Ball Race ... ..	S.V.	
19	Main Brush Gear Base Assembled less Brushes ... ..	O.H.V.	
20	Resistance Unit complete ... ..	S.V.	
21	Resistance Unit Fuse ... ..	S.V.	
	Set of Field Coils ... ..	S.V.	
	Set of Field Coils ... ..	O.H.V.	
22	Set of Brushes ... ..	S.V.	
23	Set of Brushes ... ..	O.H.V.	
	Set of Brush Springs ... ..	O.H.V.	
	Set of Brush Springs ... ..	S.V.	
	Set of Nuts, Screws and Washers ... ..	O.H.V.	
	Set of Nuts, Screws and Washers ... ..	S.V.	
24	Through Fixing Bolt ... ..	S.V.	
	Through Fixing Bolt ... ..	O.H.V.	
	<b>30F SUCTION OPERATED WINDSCREEN WIPER—Black and Chromium Finish (S.V. &amp; O.H.V.)—</b>	<b>30F/L</b>	<b>19 6 each</b>
26	Dust Band complete with Medallion ... ..	30F/ASW5EB	9 each
	Dust Band Fixing Screw ... ..	30F/AG17/265	6 dozen
27	Fixing Screw 1/4 in. long ... ..	30F/NG17/23	1 3 dozen
	Fixing Screw Washer ... ..	30F/SW560A	1 6 dozen
28	Squegee c/w Connection Piece, Split-pin and Screw (9in.) ... ..	30F/AZ111	1 6 each
29	Squegee c/w Wiper Arm, Tension Spring and Plate (9in.) ... ..	30F/AZ16	2 3 each
30	Valve Check Plate ... ..	30F/NC2201/41	2 0 dozen
31	Valve Stem ... ..	30F/NC2201/38	2 0 dozen
	Valve Stem Spring ... ..	30F/NC2201/39	1 0 dozen
	Valve Stem Washer ... ..	30F/NC2201/40	6 dozen
32	Wiper Arm complete with Spring, Plate and Bush ... ..	30F/AZ114	9 each
	<b>M11 ELECTRIC HORN 6v. (O.H.V. &amp; S.V.)—</b>	<b>M11/6v.</b>	<b>1 2 6 each</b>
33	Bell and Front Housing Assembly ... ..	M11/L2424/AB	3 0 each
34	Cover Assembly ... ..	M11/L2408/2C	1 0 each
35	Fixing Bracket ... ..	M11/L2408/4A	6 each
36	Fixing Bracket Supporting Arm ... ..	M11/L2423/3	6 each
37	Rear Housing, Motor and Yoke Assembly ... ..	M11/L2426/A	10 6 each
	Set of Brushes ... ..	M11/ST112	6 set
	Set of Nuts, Screws and Washers ... ..	M11/ST107	2 3 set

If the model and type marks on your machine are not the same as given here, please quote them in full when ordering.



RELIANT UPON GENUINE LUCAS SPARE PART





20  
78  
80  
C.E. 67.

RELY UPON GENUINE LUCAS SPARE PARTS





11011 P.V.

## DESCRIPTION.

Quote this Part No.

English  
Retail Prices.  
£ s. d.

	<b>DJ4/3 A17/0 DISTRIBUTOR (S.V.)—</b>	<b>DJ4/3 A17/0</b>	<b>1 5 6 each</b>
	<b>DJ4/3 A11/0 DISTRIBUTOR (O.H.V.)—</b>	<b>DJ4/3 A11/0</b>	<b>1 5 6 each</b>
38	Contact Breaker Lever c/w Contact Screw and Contacts ...	DJ4/ST361	3 0 set
39	Condenser complete with Clip ...	CON246	3 6 each
	Contact Screw Lock Nut ...	DJ4/398/342	6 dozen
40	Distributor Arm Assembled ...	DJ4/M2248/3	1 6 each
41	Distributor Moulded cover c/w Cable Nuts ...	DJ4/M2290/2	4 0 each
42	Distributor Moulded cover Spring/Clip ...	<b>DJ4/M2241/1A</b>	<b>2 0 dozen</b>
	Driving Dog ...	DJ4/M1106/4	6 each
	Lubricator ...	DJ4/M2023/4A	1 0 each
	Terminal Cable End ...	DJ4/M2244/4	3 dozen
43	Terminal Nut ...	DJ4/M2244/3	4 each
44	Timing Lever Assembled c/w Nut and Screw (O.H.V.) ...	DJ4/M1343/3D	1 6 each
	Timing Lever Assembled c/w Nut & Screw (S.V.) ...	DJ4/M2891/1	1 6 each
	<b>4Q6/5 A11/1 IGNITION COIL—</b>	<b>4Q6/5 A11/1</b>	<b>1 0 0 each</b>
45	Terminal Nut ...	4Q6/L373/6	9 dozen
	Terminal Nut Washer ...	4Q6/L477/2	3 dozen
	Terminal Nut Spring Washer ...	4Q6/L1002/2A	3 dozen
46	H.T. Cable Terminal Nut ...	4Q6/M2244/3	4 each
	H.T. Cable End ...	4Q6/M2244/4	3 dozen
47	Saddle Clamping Screw ...	4Q6/M2030/3	4 each
48	Saddle Clamping Screw Nut ...	4Q6/L347/1459	9 dozen
	Saddle Clamping Screw Lock Washer ...	4Q6/L1002/1	3 dozen
	<b>C/A 1331 PANEL—</b>	<b>C/A 1331</b>	<b>1 6 0 each</b>
49	Instrument Plate ...	PNL/NC56/1	4 6 each
	Warning Light ...	WL3	3 6 each
50	Warning Light Cover c/w Glass ...	PNL/LR41	6 each
	Warning Light Bulb 2.5 volts ...	MES952A	3½ each
51	D41 Dash Lamp Cover ...	PNL/SW4746	1 3 each
	D41 Dash Lamp Bulb ...	BASS.8	1 3 each
52	Ammeter ...	AMP26	5 0 each
53	PLC Switchbox ...	PLC/L	10 0 each
	PLC Switchbox Fixing Ring and Clamping Screw ...	PNL/L2428/3/Ass	4 each
	PLC Fixing Ring Screw ...	PNL/L2451/3	1 0 dozen
	PLC Switchbox Spring ...	PNL/L3809/3	3 each
	PLC Switchbox Rotor Insulating Plate ...	PN/L3790/4/Ass	1 0 each
54	PLC Switchbox Stem Assembly ...	PNL/L3972/4	1 3 each
55	PLC Switchbox Ignition Key ...	PNL/L3714/1	6 each
	PLC Switchbox Terminal Screw ...	PNL/L2483/2D	9 dozen
56	PLC Switchbox Cover Assembled c/w Switch Handle and Fixing Washer ...	PNL/L4370/2	2 6 each
	<b>CF3 CUT-OUT—</b>	<b>CF3/6v.</b>	<b>11 6 each</b>
57	SB5 Cut-out ...	CF/AZ93	6 6 each
58	Cut-out Cover ...	CF/L3306/1	8 each
59	Cut-out Cover Spring Clip ...	CF/L3586/1	2 0 dozen
60	Terminal Cover ...	CF/L3306/4A	8 each
61	Terminal Cover Spring Clip ...	CF/L3586/2	1 9 dozen
62	Fuse Carton Assembled ...	CF/L3275/4	3 0 dozen
63	Terminal Screw ...	CF/L963/5A	9 dozen
	<b>C30L JUNCTION BOX (O.H.V. Model only)—</b>	<b>C30L</b>	<b>3 0 each</b>
64	Cover complete with Insulator ...	C30/L2384/2A	3 0 dozen
65	Terminal Screw ...	C30/L963/5A	9 dozen
	<b>C31 JUNCTION BOX (S.V. Model)—</b>	<b>C31</b>	<b>3 0 each</b>
	Cover complete with Insulator ...	C31/L2578/2	3 0 dozen
	Terminal Screw ...	C31/L963/5A	9 dozen
	<b>ST8 STARTER SWITCH—</b>	<b>ST8</b>	<b>4 0 each</b>
66	Terminal Insulating Piece ...	ST8/L3870/2	9 dozen
67	Terminal Spring Washer ...	ST8/L3732/3B	3 dozen
68	Terminal Nut ...	ST8/L3585/3	1 0 dozen

If the model and type marks on your machine are not the same as given here, please quote them in full when ordering.



SIST UPON GENUINE LUCAS SPARE PART





2-10.

## DESCRIPTION.

Quote this Part No.

English  
Retail Price  
£ s. d.

	<b>No. 17 SWITCH—</b>	<b>No.17 Switch</b>	<b>10 6 each</b>
69	Horn Push Knob ... ..	NC17/2	1 3 each
	Horn Push Spring ... ..	NC17/3	9 dozen
	Cover ... ..	NC17/4	6 each
70	Fixing Screw ... ..	NC17/14	2 0 dozen
	Base ... ..	NC72/2	1 9 each
71	Clip, 1 1/4 in. diameter ... ..	NC72/4	3 each
	Clip, 1 1/2 in. diameter ... ..	NC72/5	3 each
72	Clip Screw ... ..	NC17/95	1 3 dozen
	<b>RG35P HEADLAMP C.P.R. (S.V.)—</b>	<b>RG35P/A17</b>	<b>3 10 0 pair</b>
	<b>RG35 HEADLAMP C.P.R. (O.H.V.)—</b>	<b>RG35/A11</b>	<b>3 5 0 pair</b>
73	Bulb—main ... ..	612LGD	4 3 each
74	Bulb—pilot (S.V.) ... ..	BAS.8.5	1 6 each
75	Front Rim complete with Glass ... ..	LR97	7 0 dozen
76	Front Rim Fixing Screw ... ..	RG35/SW3665	3 0 dozen
	Front Rim Locking Plate ... ..	RG35/SW4153	2 0 dozen
	Fixing Bolt Nut ... ..	RG35/SW4731	1 0 dozen
	Fixing Bolt Spring Washer ... ..	RG35/SW882	2 6 each
77	Glass (Fluted) ... ..	RG35/NC316/7	2 0 dozen
	Glass Fixing Wire ... ..	RG35/SW4736	7 6 each
78	Reflector Assembly (S.V.) ... ..	RG35/NC316/9	6 6 each
79	Reflector Assembly (O.H.V.) ... ..	RG35/NC316/8	9 dozen
	Reflector Fixing Screw ... ..	RG35/SW4528	3 0 dozen
80	Reflector Joint Bead ... ..	RG35/SW4583	
	<b>1120 SIDELAMP C.P.R. (O.H.V.)—</b>	<b>1120/CPR/6v.</b>	<b>17 6 pair</b>
	Bulb ... ..	BAS.8.5	1 3 each
81	Front Rim complete with Glass ... ..	1120/LR48	2 3 each
82	Glass ... ..	1120/L454	3 0 dozen
83	Reflector complete with Bulb Holder Interior ... ..	1120/L463	1 6 each
	<b>T101 TAIL LAMP (S.V. &amp; O.H.V.)—</b>	<b>T101/Blk.</b>	<b>8 0 each</b>
	Body complete with Ruby and Clear Windows ... ..	T101/SO255	1 9 each
84	Bulb ... ..	BAS.8.5	1 3 each
85	Bulb Holder Spring ... ..	T101/SW4868	1 6 dozen
	Bulb Holder Insulating Washer—brown ... ..	T101/SW4842	1 0 dozen
	Bulb Holder Insulating Washer—white ... ..	T101/SW4850	1 6 dozen
	Cable Rubber Washer ... ..	T101/SW4825	1 0 dozen
	Fixing Screw Spring Washer ... ..	T101/L760/5	6 dozen
	Fixing Screw ... ..	T101/SW4785	1 6 dozen
86	Fixing Shell Assembly ... ..	T101/SO256	1 6 each
	<b>STW9E BATTERY (S.V.)—</b>	<b>STW9E Dry</b>	<b>2 8 6 each</b>
	Set of Fixing Rods ... ..	STW/ST405	2 0 set
	Terminal Lug—positive ... ..	STW/B132	1 6 each
	Terminal Lug—negative ... ..	STW/B133	1 6 each
	Vent Plug with Washer ... ..	STW/B128	6 each
	<b>STW11E BATTERY (O.H.V.)—</b>	<b>STW11E Dry</b>	<b>2 12 6 each</b>
	Terminal Lug—positive ... ..	STW/B132	1 6 each
	Terminal Lug—negative ... ..	STW/B133	1 6 each
	Vent Plug with Washer ... ..	STW/B128	6 each
	Set of Fixing Rods ... ..	STW/ST232	2 0 set

If the model and type marks on your machine are not the same as given here, please quote them in full when ordering.



RELIANT UPON GENUINE LUCAS SPARE PARTS

