


PLATE A





B10

B13



B14

B13

B19

B18

B16

B17

B15



B17



B15



B24



B16



B11



B14



B19



B37



B38



B53



B36



B27



B35



B39



B29



B34



B30



B32



B31



B45



B25



B33



B54



B52



B26



B41



B43



B28



B40



B42



B44



B48



B50



B46



B51



B49



B47



B20



B21



B23



B18



B22

* O.H.V. and Family Eight models only.

† Not used









PLATE D









L1



L2



L10



L22
L35 L36



L31



L12 L13



L8



L4



L32



L34



L7



L6



L9



L17



L25



L15



L14



L3



L11



L28



L16



L23



L18



L20



L19



L21 L26



L30




L27




L29



L33





See Plate A 100



ATE P

STARTER.



